

# ASAS INOX

STAINLESS STEEL HANDLES  
 ASAS ACERO INOXIDABLE  
 TIREURS ACIER INOXYDABLE

## ASA INOX 91



› PUX. 91.20 Ø(20mm)

- |              |           |
|--------------|-----------|
| 1. A = 200mm | B = 350mm |
| 2. A = 250mm | B = 400mm |
| 3. A = 300mm | B = 450mm |
| 4. A = 450mm | B = 600mm |
| 5. A = 550mm | B = 700mm |
| >700         |           |

› PUX. 91.25 Ø(25mm)

- |               |            |
|---------------|------------|
| 1. A = 250mm  | B = 400mm  |
| 2. A = 300mm  | B = 450mm  |
| 3. A = 450mm  | B = 600mm  |
| 4. A = 600mm  | B = 750mm  |
| 5. A = 900mm  | B = 1050mm |
| 6. A = 1800mm | B = 1950   |
| >1950         |            |

› PUX. 91.30 Ø(30mm)

- |               |            |
|---------------|------------|
| 1. A = 300mm  | B = 450mm  |
| 2. A = 350mm  | B = 500mm  |
| 3. A = 450mm  | B = 600mm  |
| 4. A = 600mm  | B = 750mm  |
| 5. A = 900mm  | B = 1050mm |
| 6. A = 1800mm | B = 1950   |
| >1950         |            |

› PUX. 91.35 Ø(35mm)

- |               |            |
|---------------|------------|
| 1. A = 450mm  | B = 600mm  |
| 2. A = 600mm  | B = 750mm  |
| 3. A = 900mm  | B = 1050mm |
| 4. A = 1800mm | B = 1950mm |
| >1950         |            |

› PUX. 91.40 Ø(40mm)

- |               |            |
|---------------|------------|
| 1. A = 600mm  | B = 750mm  |
| 2. A = 900mm  | B = 1050mm |
| 3. A = 1800mm | B = 1950mm |
| >1950         |            |

